PlcDeviceConnectionStateChangedEventArgs Members

Namespace: IPS7Lnk.Advanced
Assemblies: IPS7LnkNet.Advanced.dll, IPS7LnkNet.Advanced.dll
The PlcDeviceConnectionStateChangedEventArgs type exposes the following members.

Constructors

PlcDeviceConnectionStateChangedEventArgs(PlcDeviceConnectionState, PlcDeviceConnectionState)

Initializes a new instance of the PlcDeviceConnectionStateChangedEventArgs class using the specified `oldState` and `newState`.

C#

```
public PlcDeviceConnectionStateChangedEventArgs(PlcDeviceConnectionState oldState,
PlcDeviceConnectionState newState)
```

Parameters

`oldState` PlcDeviceConnectionState

The state before the change.

`newState` PlcDeviceConnectionState

The state after the change.

Properties

NewState

Gets the state after the change.

C#

```
public PlcDeviceConnectionState NewState { get; }
```

Property Value

PlcDeviceConnectionState

The PlcDeviceConnectionState after the change.

OldState

Gets the state before the change.

C#

```
public PlcDeviceConnectionState OldState { get; }
```

Property Value

PlcDeviceConnectionState

The PlcDeviceConnectionState before the change.

Table of Contents

Constructors 1
PlcDeviceConnectionStateChangedEventArgs(PlcDeviceConnectionState, PlcDeviceConnectionState) 1
Properties 1
NewState 1
OldState 2