



# Core API

## AddNodes Service

This service is used to add additional nodes the address space of a Server through a Client application. Use the components here to define the different nodes to add as the Server would define them. The following types also support simple creation of whole trees without the need to manually define each node of the tree using single requests.

- [OpcAddNode](#)
- [OpcAddNodeCollection](#)
- [OpcAddNodeResult](#)
- [OpcAddNodeResultCollection](#)
- [OpcAddInstanceNode](#)
- [OpcAddObjectNode](#)
- [OpcAddObjectNode.TypeDefinition](#)
- [OpcAddFolderNode](#)
- [OpcAddPropertyNode](#)
- [OpcAddVariableNode](#)
- [OpcAddVariableNode.TypeDefinition](#)
- [OpcAddDataVariableNode](#)
- [OpcAddAnalogItemNode](#)
- [OpcAddDataItemNode](#)
- [OpcAddObjectTypeNode](#)
- [OpcAddVariableTypeNode](#)
- [OpcAddTypeNode](#)



# Table of Contents

|                               |   |
|-------------------------------|---|
| <b>AddNodes Service</b> ..... | 1 |
|-------------------------------|---|