

Rfc1006IPEndPoint.LocalTSAP Property

Gets or sets the local TSAP of the endpoint.

Namespace: [Rfc1006LibNet.Advanced](#)

Assembly: Rfc1006LibNet.Advanced (in Rfc1006LibNet.Advanced.dll) Version: 1.0.2.0 (1.0.5.3)

Syntax

C#

```
public byte[] LocalTSAP { get; set; }
```

Property Value

Type: [Byte\[\]](#)

See Also

Reference

[Rfc1006IPEndPoint Class](#)

[Rfc1006LibNet.Advanced Namespace](#)

Table of Contents

Syntax	1
Property Value	1
See Also	1
Reference	1