

# PlcDeviceConnectionStateChangedEventArgs Class

**Namespace:** IPS7Lnk.Advanced

**Assemblies:** IPS7LnkNet.Advanced.dll

Provides the event data for the [StateChanged](#) event.

**C#**

```
public class PlcDeviceConnectionStateChangedEventArgs : EventArgs
```

**Inheritance** [Object](#) > [EventArgs](#) > [PlcDeviceConnectionStateChangedEventArgs](#)

## Constructors

| Name                                                                                                         | Description                                                                                                                                                |
|--------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">PlcDeviceConnectionStateChangedEventArgs(PlcDeviceConnectionState, PlcDeviceConnectionState)</a> | Initializes a new instance of the <a href="#">PlcDeviceConnectionStateChangedEventArgs</a> class using the specified <b>oldState</b> and <b>newState</b> . |

## Properties

| Name                     | Description                       |
|--------------------------|-----------------------------------|
| <a href="#">NewState</a> | Gets the state after the change.  |
| <a href="#">OldState</a> | Gets the state before the change. |



# Table of Contents

|                     |   |
|---------------------|---|
| <b>Constructors</b> | 1 |
| <b>Properties</b>   | 1 |