

ValueChangedEventArgs<T>

Members

Namespace: IPS7Lnk.Advanced

Assemblies: IPS7LnkNet.Advanced.dll, IPS7LnkNet.Advanced.dll

The [ValueChangedEventArgs<T>](#) type exposes the following members.

Constructors

ValueChangedEventArgs(T, T)

Initializes a new instance of the [ValueChangedEventArgs`1](#) class using the [oldValue](#) and [newValue](#) specified.

C#

```
public ValueChangedEventArgs(T oldValue, T newValue)
```

Parameters

[oldValue](#) T

The old value before [newValue](#) has been applied.

[newValue](#) T

The new value which substitutes the [oldValue](#).

Properties

NewValue

Gets the new value which substitutes the [OldValue](#).

C#

```
public T NewValue { get; }
```

Property Value

T

The new value of [T](#).

OldValue

Gets the old value before **NewValue** has been applied.

C#

```
public T OldValue { get; }
```

Property Value

T

The old value of T.

Table of Contents

Constructors	1
ValueChangedEventArgs(T, T)	1
Properties	1
NewValue	1
OldValue	2

