

OpcAddDataVariableNode<T> Members

Namespace: Opc.UaFx

Assemblies: Opc.UaFx.Advanced.dll, Opc.UaFx.Advanced.dll

The [OpcAddDataVariableNode<T>](#) type exposes the following members.

Constructors

OpcAddDataVariableNode(OpcName)

Initializes a new instance of the [OpcAddDataVariableNode`1](#) class using the `name` of the data variable node to add. The according [OpcNodeId](#) to identify and access the new node is determined by the service. The new node will be a child of the [ObjectsFolder](#) node using [HasComponent](#) as the type of reference.

C#

```
public OpcAddDataVariableNode(OpcName name)
```

Parameters

`name` [OpcName](#)

The [OpcName](#) through that the new data variable node can be accessed.

Exceptions

[ArgumentException](#)

The `name` is equals `Null`.

[ArgumentNullException](#)

The `name` is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcName, OpcNodeId)

Initializes a new instance of the [OpcAddDataVariableNode`1](#) class using the `name` of the data variable node to add, which shall be additionally accessible by the `nodeId` defined. The new node will be a child of the [ObjectsFolder](#) node using [HasComponent](#) as the type of reference.

C#

```
public OpcAddDataVariableNode(OpcName name, OpcNodeId nodeId)
```

Parameters

`name` [OpcName](#)

The **OpcName** through that the new data variable node can be accessed.

nodeId **OpcNodeld**

The **OpcNodeld** through that the new node can be identified and accessed. In case there **Null** is specified the server will determine the according **OpcNodeld** by its own.

Exceptions

ArgumentException

The **name** is equals **Null**.

ArgumentNullException

The **name** or **nodeId** is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcName, OpcNodeld, OpcNodeld)

Initializes a new instance of the **OpcAddDataVariableNode`1** class using the **name** of the data variable node to add, which shall be additionally accessible by the **nodeId** defined. The new node will be a child of the node identified by **parentNode** using **HasComponent** as the type of reference.

C#

```
public OpcAddDataVariableNode(OpcName name, OpcNodeId nodeId, OpcNodeId parentNodeId)
```

Parameters

name **OpcName**

The **OpcName** through that the new data variable node can be accessed.

nodeId **OpcNodeld**

The **OpcNodeld** through that the new node can be identified and accessed. In case there **Null** is specified the server will determine the according **OpcNodeld** by its own.

parentNode **OpcNodeld**

The **OpcNodeld** of the parent node to reference using **HasComponent** as the type of reference.

Exceptions

ArgumentException

The **parentNode** is equals **Null** or **name** is equals **Null**.

ArgumentNullException

The **name**, **nodeId** or **parentNode** is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcName, OpcNodeId, OpcNodeId, OpcNodeId)

Initializes a new instance of the `OpcAddDataVariableNode`1` class using the `name` of the data variable node to add, which shall be additionally accessible by the `nodeId` defined. The new node will be a child of the node identified by `parentNodeId` using the type of reference identified by the `referenceTypeId` specified.

C#

```
public OpcAddDataVariableNode(OpcName name, OpcNodeId nodeId, OpcNodeId parentNodeId,
OpcNodeId referenceTypeId)
```

Parameters

`name` `OpcName`

The `OpcName` through that the new data variable node can be accessed.

`nodeId` `OpcNodeId`

The `OpcNodeId` through that the new node can be identified and accessed. In case there `Null` is specified the server will determine the according `OpcNodeId` by its own.

`parentNodeId` `OpcNodeId`

The `OpcNodeId` of the parent node to reference using the type of reference identified by `referenceTypeId`.

`referenceTypeId` `OpcNodeId`

The `OpcNodeId` which identifies the type of reference to use for the new node and the existing parent node identified by `parentNodeId`.

Exceptions

`ArgumentException`

The `parentNodeId` or `referenceTypeId` is equals `Null` or `name` is equals `Null`.

`ArgumentNullException`

The `name`, `nodeId`, `parentNodeId` or `referenceTypeId` is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcName, OpcNodeId, OpcNodeId, OpcNodeId, T)

Initializes a new instance of the `OpcAddDataVariableNode`1` class using the `name` of the data variable node to add, which shall be additionally accessible by the `nodeId` defined. The new node will be a child of the node identified by `parentNodeId` using the type of reference identified by the `referenceTypeId` specified.

C#

```
public OpcAddDataVariableNode(OpcName name, OpcNodeId nodeId, OpcNodeId parentNodeId,
OpcNodeId referenceTypeId, T value)
```

Parameters

`name OpcName`

The `OpcName` through that the new data variable node can be accessed.

`nodeId OpcNodeId`

The `OpcNodeId` through that the new node can be identified and accessed. In case there `Null` is specified the server will determine the according `OpcNodeId` by its own.

`parentNodeId OpcNodeId`

The `OpcNodeId` of the parent node to reference using the type of reference identified by `referenceTypeId`.

`referenceTypeId OpcNodeId`

The `OpcNodeId` which identifies the type of reference to use for the new node and the existing parent node identified by `parentNodeId`.

`value T`

The initial value of the new data variable node.

Exceptions

`ArgumentException`

The `parentNodeID` or `referenceTypeId` is equals `Null` or `name` is equals `Null`.

`ArgumentNullException`

The `name`, `nodeId`, `parentNodeId` or `referenceTypeId` is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcName, OpcNodeId, OpcNodeId, OpcReferenceType)

Initializes a new instance of the `OpcAddDataVariableNode`1` class using the `name` of the data variable node to add, which shall be additionally accessible by the `nodeId` defined. The new node will be a child of the node identified by `parentNodeId` using the `referenceType` specified as the type of reference.

C#

```
public OpcAddDataVariableNode(OpcName name, OpcNodeId nodeId, OpcNodeId parentNodeId,
OpcReferenceType referenceType)
```

Parameters

`name OpcName`

The `OpcName` through that the new data variable node can be accessed.

`nodeId OpcNodeId`

The `OpcNodeId` through that the new node can be identified and accessed. In case there `Null` is specified the server will determine the according `OpcNodeId` by its own.

parentNodeId OpcNodeId

The [OpcNodeId](#) of the parent node to reference using [HasComponent](#) as the type of reference.

referenceType OpcReferenceType

One of the members defined by the [OpcReferenceType](#) enumeration to use to setup the reference between the new node and the existing parent node identified by [parentNodeId](#).

Exceptions

ArgumentException

The [parentNodeId](#) is equals [Null](#) or [name](#) is equals [Null](#).

ArgumentNullException

The [name](#), [nodeId](#) or [parentNodeId](#) is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcName, OpcNodeId, OpcNodeId, OpcReferenceType, T)

Initializes a new instance of the [OpcAddDataVariableNode`1](#) class using the [name](#) of the data variable node to add, which shall be additionally accessible by the [nodeId](#) defined. The new node will be a child of the node identified by [parentNodeId](#) using the [referenceType](#) specified as the type of reference.

C#

```
public OpcAddDataVariableNode(OpcName name, OpcNodeId nodeId, OpcNodeId parentNodeId,  
OpcReferenceType referenceType, T value)
```

Parameters

name OpcName

The [OpcName](#) through that the new data variable node can be accessed.

nodeId OpcNodeId

The [OpcNodeId](#) through that the new node can be identified and accessed. In case there [Null](#) is specified the server will determine the according [OpcNodeId](#) by its own.

parentNodeId OpcNodeId

The [OpcNodeId](#) of the parent node to reference using [HasComponent](#) as the type of reference.

referenceType OpcReferenceType

One of the members defined by the [OpcReferenceType](#) enumeration to use to setup the reference between the new node and the existing parent node identified by [parentNodeId](#).

value T

The initial value of the new data variable node.

Exceptions

ArgumentException

The `parentNodeId` is equals `Null` or `name` is equals `Null`.

ArgumentNullException

The `name`, `nodeId` or `parentNodeId` is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcName, OpcNodeId, OpcNodeId, T)

Initializes a new instance of the `OpcAddDataVariableNode`1` class using the `name` of the data variable node to add, which shall be additionally accessible by the `nodeId` defined. The new node will be a child of the node identified by `parentNodeId` using `HasComponent` as the type of reference.

C#

```
public OpcAddDataVariableNode(OpcName name, OpcNodeId nodeId, OpcNodeId parentNodeId, T value)
```

Parameters

`name` OpcName

The `OpcName` through that the new data variable node can be accessed.

`nodeId` OpcNodeId

The `OpcNodeId` through that the new node can be identified and accessed. In case there `Null` is specified the server will determine the according `OpcNodeId` by its own.

`parentNodeId` OpcNodeId

The `OpcNodeId` of the parent node to reference using `HasComponent` as the type of reference.

`value` T

The initial value of the new data variable node.

Exceptions

ArgumentException

The `parentNodeId` is equals `Null` or `name` is equals `Null`.

ArgumentNullException

The `name`, `nodeId` or `parentNodeId` is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcName, OpcNodeId, T)

Initializes a new instance of the `OpcAddDataVariableNode`1` class using the `name` of the data variable node to add, which shall be additionally accessible by the `nodeId` defined. The new node will be a child of the `ObjectsFolder` node using `HasComponent` as the type of reference.

C#

```
public OpcAddDataVariableNode(OpcName name, OpcNodeId nodeId, T value)
```

Parameters

name OpcName

The **OpcName** through that the new data variable node can be accessed.

nodeId OpcNodeId

The **OpcNodeId** through that the new node can be identified and accessed. In case there **Null** is specified the server will determine the according **OpcNodeId** by its own.

value T

The initial value of the new data variable node.

Exceptions

ArgumentException

The **name** is equals **Null**.

ArgumentNullException

The **name** or **nodeId** is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcName, T)

Initializes a new instance of the **OpcAddDataVariableNode`1** class using the **name** of the data variable node to add. The according **OpcNodeId** to identify and access the new node is determined by the service. The new node will be a child of the **ObjectsFolder** node using **HasComponent** as the type of reference.

C#

```
public OpcAddDataVariableNode(OpcName name, T value)
```

Parameters

name OpcName

The **OpcName** through that the new data variable node can be accessed.

value T

The initial value of the new data variable node.

Exceptions

ArgumentException

The **name** is equals **Null**.

ArgumentNullException

The `name` is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcVariableType, OpcName)

Initializes a new instance of the `OpcAddDataVariableNode`1` class using the specified `type` of data variable node to add, which shall be accessible by the `name` defined. The according `OpcNodeId` to identify and access the new node is determined by the service. The new node will be a child of the `ObjectsFolder` node using `HasComponent` as the type of reference.

C#

```
protected OpcAddDataVariableNode(OpcVariableType type, OpcName name)
```

Parameters

type OpcVariableType

One of the members defined by the `OpcVariableType` enumeration which identifies the predefined underlying type definition the new node will represent an instance of.

name OpcName

The `OpcName` through that the new data variable node can be accessed.

Exceptions

ArgumentException

The `name` is equals `Null`.

ArgumentNullException

The `name` is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId)

Initializes a new instance of the `OpcAddDataVariableNode`1` class using the specified `type` of data variable node to add, which shall be accessible by the `name` and `nodeId` defined. The new node will be a child of the `ObjectsFolder` node using `HasComponent` as the type of reference.

C#

```
protected OpcAddDataVariableNode(OpcVariableType type, OpcName name, OpcNodeId nodeId)
```

Parameters

type OpcVariableType

One of the members defined by the `OpcVariableType` enumeration which identifies the predefined underlying type definition the new node will represent an instance of.

name OpcName

The [OpcName](#) through that the new data variable node can be accessed.

nodeId OpcNodeId

The [OpcNodeId](#) through that the new node can be identified and accessed. In case there [Null](#) is specified the server will determine the according [OpcNodeId](#) by its own.

Exceptions

[ArgumentException](#)

The [name](#) is equals [Null](#).

[ArgumentNullException](#)

The [name](#) or [nodeId](#) is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId, OpcNodeId)

Initializes a new instance of the [OpcAddDataVariableNode`1](#) class using the specified [type](#) of data variable node to add, which shall be accessible by the [name](#) and [nodeId](#) defined. The new node will be a child of the node identified by [parentNodeID](#) using [HasComponent](#) as the type of reference.

C#

```
protected OpcAddDataVariableNode(OpcVariableType type, OpcName name, OpcNodeId nodeId,  
OpcNodeId parentNodeId)
```

Parameters

type OpcVariableType

One of the members defined by the [OpcVariableType](#) enumeration which identifies the predefined underlying type definition the new node will represent an instance of.

name OpcName

The [OpcName](#) through that the new data variable node can be accessed.

nodeId OpcNodeId

The [OpcNodeId](#) through that the new node can be identified and accessed. In case there [Null](#) is specified the server will determine the according [OpcNodeId](#) by its own.

parentNodeID OpcNodeId

The [OpcNodeId](#) of the parent node to reference using [HasComponent](#) as the type of reference.

Exceptions

[ArgumentException](#)

The [parentNodeID](#) is equals [Null](#) or [name](#) is equals [Null](#).

ArgumentNullException

The `name`, `nodeId` or `parentNodeId` is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId, OpcNodeId, OpcNodeId)

Initializes a new instance of the `OpcAddDataVariableNode`1` class using the specified `type` of data variable node to add, which shall be accessible by the `name` and `nodeId` defined. The new node will be a child of the node identified by `parentNodeId` using the type of reference identified by the `referenceTypeId` specified.

C#

```
protected OpcAddDataVariableNode(OpcVariableType type, OpcName name, OpcNodeId nodeId,  
OpcNodeId parentNodeId, OpcNodeId referenceTypeId)
```

Parameters

`type` `OpcVariableType`

One of the members defined by the `OpcVariableType` enumeration which identifies the predefined underlying type definition the new node will represent an instance of.

`name` `OpcName`

The `OpcName` through that the new data variable node can be accessed.

`nodeId` `OpcNodeId`

The `OpcNodeId` through that the new node can be identified and accessed. In case there `Null` is specified the server will determine the according `OpcNodeId` by its own.

`parentNodeId` `OpcNodeId`

The `OpcNodeId` of the parent node to reference using the type of reference identified by `referenceTypeId`.

`referenceTypeId` `OpcNodeId`

The `OpcNodeId` which identifies the type of reference to use for the new node and the existing parent node identified by `parentNodeId`.

Exceptions

`ArgumentException`

The `parentNodeId` or `referenceTypeId` is equals `Null` or `name` is equals `Null`.

`ArgumentNullException`

The `name`, `nodeId`, `parentNodeId` or `referenceTypeId` is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcVariableType, OpcName,

OpcNodeId, OpcNodeId, OpcNodeId, T)

Initializes a new instance of the `OpcAddDataVariableNode`1` class using the specified `type` of data variable node to add, which shall be accessible by the `name` and `nodeId` defined. The new node will be a child of the node identified by `parentNodeId` using the type of reference identified by the `referenceTypeId` specified.

C#

```
protected OpcAddDataVariableNode(OpcVariableType type, OpcName name, OpcNodeId nodeId,
OpcNodeId parentNodeId, OpcNodeId referenceTypeId, T value)
```

Parameters

`type` OpcVariableType

One of the members defined by the `OpcVariableType` enumeration which identifies the predefined underlying type definition the new node will represent an instance of.

`name` OpcName

The `OpcName` through that the new data variable node can be accessed.

`nodeId` OpcNodeId

The `OpcNodeId` through that the new node can be identified and accessed. In case there `Null` is specified the server will determine the according `OpcNode` by its own.

`parentNodeId` OpcNodeId

The `OpcNode` of the parent node to reference using the type of reference identified by `referenceTypeId`.

`referenceTypeId` OpcNode

The `OpcNode` which identifies the type of reference to use for the new node and the existing parent node identified by `parentNodeId`.

`value` T

The initial value of the new data variable node.

Exceptions

ArgumentException

The `parentNodeId` or `referenceTypeId` is equals `Null` or `name` is equals `Null`.

ArgumentNullException

The `name`, `nodeId`, `parentNodeId` or `referenceTypeId` is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId, OpcNodeId, OpcReferenceType)

Initializes a new instance of the `OpcAddDataVariableNode`1` class using the specified `type` of data variable node to add, which shall be accessible by the `name` and `nodeId` defined. The new node will be a child of the node identified by `parentNodeId` using the `referenceType` specified as the type of reference.

C#

```
protected OpcAddDataVariableNode(OpcVariableType type, OpcName name, OpcNodeId nodeId,
OpcNodeId parentNodeId, OpcReferenceType referenceType)
```

Parameters

type `OpcVariableType`

One of the members defined by the `OpcVariableType` enumeration which identifies the predefined underlying type definition the new node will represent an instance of.

name `OpcName`

The `OpcName` through that the new data variable node can be accessed.

nodeId `OpcNodeId`

The `OpcNodeId` through that the new node can be identified and accessed. In case there `Null` is specified the server will determine the according `OpcNodeId` by its own.

parentNodeId `OpcNodeId`

The `OpcNodeId` of the parent node to reference using `HasComponent` as the type of reference.

referenceType `OpcReferenceType`

One of the members defined by the `OpcReferenceType` enumeration to use to setup the reference between the new node and the existing parent node identified by `parentNodeId`.

Exceptions

ArgumentException

The `parentNodeId` is equals `Null` or `name` is equals `Null`.

ArgumentNullException

The `name`, `nodeId` or `parentNodeId` is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId, OpcNodeId, OpcReferenceType, T)

Initializes a new instance of the `OpcAddDataVariableNode`1` class using the specified `type` of data variable node to add, which shall be accessible by the `name` and `nodeId` defined. The new node will be a child of the node identified by `parentNodeId` using the `referenceType` specified as the type of reference.

C#

```
protected OpcAddDataVariableNode(OpcVariableType type, OpcName name, OpcNodeId nodeId,
OpcNodeId parentNodeId, OpcReferenceType referenceType, T value)
```

Parameters

type `OpcVariableType`

One of the members defined by the [OpcVariableType](#) enumeration which identifies the predefined underlying type definition the new node will represent an instance of.

name OpcName

The [OpcName](#) through that the new data variable node can be accessed.

nodeId OpcNodeld

The [OpcNodeld](#) through that the new node can be identified and accessed. In case there [Null](#) is specified the server will determine the according [OpcNodeld](#) by its own.

parentNode OpcNodeld

The [OpcNodeld](#) of the parent node to reference using [HasComponent](#) as the type of reference.

referenceType OpcReferenceType

One of the members defined by the [OpcReferenceType](#) enumeration to use to setup the reference between the new node and the existing parent node identified by [parentNode](#).

value T

The initial value of the new data variable node.

Exceptions

ArgumentException

The [parentNode](#) is equals [Null](#) or [name](#) is equals [Null](#).

ArgumentNullException

The [name](#), [nodeId](#) or [parentNode](#) is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeld, OpcNodeld, T)

Initializes a new instance of the [OpcAddDataVariableNode`1](#) class using the specified [type](#) of data variable node to add, which shall be accessible by the [name](#) and [nodeId](#) defined. The new node will be a child of the node identified by [parentNode](#) using [HasComponent](#) as the type of reference.

C#

```
protected OpcAddDataVariableNode(OpcVariableType type, OpcName name, OpcNodeId nodeId,
OpcNodeId parentNode, T value)
```

Parameters

type OpcVariableType

One of the members defined by the [OpcVariableType](#) enumeration which identifies the predefined underlying type definition the new node will represent an instance of.

name OpcName

The [OpcName](#) through that the new data variable node can be accessed.

nodeId OpcNodeId

The [OpcNodeId](#) through that the new node can be identified and accessed. In case there [Null](#) is specified the server will determine the according [OpcNodeId](#) by its own.

parentNode Id OpcNodeId

The [OpcNodeId](#) of the parent node to reference using [HasComponent](#) as the type of reference.

value T

The initial value of the new data variable node.

Exceptions

ArgumentException

The [parentNode Id](#) is equals [Null](#) or [name](#) is equals [Null](#).

ArgumentNullException

The [name](#), [nodeId](#) or [parentNode Id](#) is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId, T)

Initializes a new instance of the [OpcAddDataVariableNode`1](#) class using the specified [type](#) of data variable node to add, which shall be accessible by the [name](#) and [nodeId](#) defined. The new node will be a child of the [ObjectsFolder](#) node using [HasComponent](#) as the type of reference.

C#

```
protected OpcAddDataVariableNode(OpcVariableType type, OpcName name, OpcNodeId nodeId, T value)
```

Parameters

type OpcVariableType

One of the members defined by the [OpcVariableType](#) enumeration which identifies the predefined underlying type definition the new node will represent an instance of.

name OpcName

The [OpcName](#) through that the new data variable node can be accessed.

nodeId OpcNodeId

The [OpcNodeId](#) through that the new node can be identified and accessed. In case there [Null](#) is specified the server will determine the according [OpcNodeId](#) by its own.

value T

The initial value of the new data variable node.

Exceptions

ArgumentException

The `name` is equals `Null`.

ArgumentNullException

The `name` or `nodeId` is a null reference (Nothing in Visual Basic).

OpcAddDataVariableNode(OpcVariableType, OpcName, T)

Initializes a new instance of the `OpcAddDataVariableNode`1` class using the specified `type` of data variable node to add, which shall be accessible by the `name` defined. The according `OpcNodeID` to identify and access the new node is determined by the service. The new node will be a child of the `ObjectsFolder` node using `HasComponent` as the type of reference.

C#

```
protected OpcAddDataVariableNode(OpcVariableType type, OpcName name, T value)
```

Parameters

`type` OpcVariableType

One of the members defined by the `OpcVariableType` enumeration which identifies the predefined underlying type definition the new node will represent an instance of.

`name` OpcName

The `OpcName` through that the new data variable node can be accessed.

`value` T

The initial value of the new data variable node.

Exceptions

ArgumentException

The `name` is equals `Null`.

ArgumentNullException

The `name` is a null reference (Nothing in Visual Basic).

Properties

DataType

Gets or sets a value which defines a pre-defined used `DataTypeld` as one of the members defined by the `OpcDataType` enumeration to simplify querying standard data types. A null reference (Nothing in Visual Basic) indicates that the attribute is undefined and its default value is used.

C#

```
public override OpcDataType? DataType { get; set; }
```

Property Value

Nullable<OpcDataType>

One of the members defined by the [OpcDataType](#) enumeration.

Value

Gets or sets the value of the data variable node. A null reference (Nothing in Visual Basic) indicates that the attribute is undefined and its default value is used.

C#

```
public T Value { get; set; }
```

Property Value

T

A T representing the value of the data variable node. This can be also a null reference (Nothing in Visual Basic).

Table of Contents

Constructors	1
OpcAddDataVariableNode(OpcName)	1
OpcAddDataVariableNode(OpcName, OpcNodeId)	1
OpcAddDataVariableNode(OpcName, OpcNodeId, OpcNodeId)	2
OpcAddDataVariableNode(OpcName, OpcNodeId, OpcNodeId, OpcNodeId)	3
OpcAddDataVariableNode(OpcName, OpcNodeId, OpcNodeId, OpcNodeId, OpcNodeId, T)	3
OpcAddDataVariableNode(OpcName, OpcNodeId, OpcNodeId, OpcReferenceType)	4
OpcAddDataVariableNode(OpcName, OpcNodeId, OpcNodeId, OpcReferenceType, T)	5
OpcAddDataVariableNode(OpcName, OpcNodeId, OpcNodeId, OpcNodeId, T)	6
OpcAddDataVariableNode(OpcName, OpcNodeId, T)	6
OpcAddDataVariableNode(OpcName, T)	7
OpcAddDataVariableNode(OpcVariableType, OpcName)	8
OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId)	8
OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId, OpcNodeId)	9
OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId, OpcNodeId, OpcNodeId)	
.....	10
OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId, OpcNodeId, OpcNodeId, T)	
.....	10
OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId, OpcNodeId,	
OpcReferenceType)	11
OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId, OpcNodeId,	
OpcReferenceType, T)	12
OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId, OpcNodeId, T)	13
OpcAddDataVariableNode(OpcVariableType, OpcName, OpcNodeId, T)	14
OpcAddDataVariableNode(OpcVariableType, OpcName, T)	15
Properties	15
DataType	15
Value	16

